

Daily Pot Corrector and Concealer

Formula # 4/19-163/883/154-4

Features

- Anhydrous Concealer with Medium to Full Coverage
- One Swipe Application
- Functional System with Room to Play from Matte to Dewy

Color Cosmetics

Anhydrous

Traditional Ingredients

Formula

Kester Wax K-82P

Unique plasticizer. High melt point soft wax improves stability, compatibility, and feel of anhydrous systems without affecting structure. Creates jellies and squeezables. Usage level 0.25-20%.

SynKos Wax 2060

Synthetic wax that increases melt point and provides hard structure in anhydrous formulas, mimics the properties of medium melt paraffins, ozokerites, polyethylenes. Economical, versatile structurant.

Kester Wax K-24

Naturally derived wax ester of plant origin. Low melt point semi-solid, melts on body contact, provides cooling sensation. Adds slip, reduces greasy feel, dimethicone alternative. Usage level up to 50%.

Trade Name	INCI Name	%
<i>Phase A</i>		
Enhans SB-63 ¹	Bis-PEG-12 Dimethicone Beeswax	15.5
SynKos 2060 ¹	Synthetic Wax	3.0
Kester Wax K-24 ¹	Lauryl Laurate	5.5
Kester Wax K-82P ¹	C 18-38 Alkyl Hydroxystearoyl Stearate	6.0
Jeechem OP ²	Octyl Palmitate	10.0
Belsil PDM 20 ³	Trimethylsiloxypheyl Dimethicone	12.0
<i>Phase B</i>		
Jeechem CTG ²	Caprylic/Capric Triglyceride	18.00
Titanium Dioxide ⁴	Titanium Dioxide CI 77891	14.80
Unipure Black LC 989 ⁴	Iron Oxides CI 77499	0.20
Unipure Red LC 381 ⁴	Iron Oxides CI 77491	0.76
Unipure LC 182 ⁴	Iron Oxides CI 77492	2.44
Mica Sericite ³	Mica	3.80
<i>Phase C</i>		
Permethyll 99A ⁵	Isododecane	8.0

Procedure

- Combine Phase B (Color Base) ingredients and mix until homogeneous, milling if needed.
- Combine Phase A ingredients, heat to 85–90°C and mix until uniform.
- Slowly add Phase B to A with mixing, continuing until uniform.
- Add Phase C to batch, mix quickly to avoid loss. Pour into containers around 80°C.

Stability Information:

One month at 45 °C, one month at room temperature, three freeze/thaw cycles.

Supplier Information:

1. Koster Keunen, Inc.;
2. Jeen;
3. Brenntag Specialties;
4. Sensient;
5. Presperse.

Looking for additional formulas? Try our Formula Selector Tool at: kosterkeunen.com/pcformulationguide